


Spare Parts



Replacement Parts are available from: See Back Cover for Address.

Ref No.	Part No.	Description
1	10/12212	Union Nut, Heat Exchanger
2	10/12213	Comp. Flange, Brnz. Heat Exchanger
3	20/10047	'O' Ring - Heat Exchanger
4	10/13843	Outlet Adaptor, ECO @ HX
5	10/12731	ADP Assembly In/Out
6	10/10062	Direct Vent Flu Seal
7	10/10196	Heat Exchanger Seal
8	10/14689	Heat Exchanger
9	10/10075	Direct Vent Case Seal
10	10/19030	DV Cover - White
11	10/13056	CF Cover - White
12	10/19224	CF Bottom Cover - Grey
	10/19226	DV Bottom Cover - Grey
13	10/19055	ECO Assembly With Leads From Serial No. 15 000 000 0 and newer
14	10/13849	Thermocouple Connector
15	10/13846	Interrupter Insert
16	10/13848	Thermocouple
17	12/13055	Fix/nut Thermocouple
18	22/13059	Pilot Mounting Assembly
19	10/12872	Pilot Tube Assembly - NG
	10/12873	Pilot Tube Assembly - LP Gas
20	10/12259	Electrode Assembly
21	10/12694	Pilot Filter
22	10/13706	FSD Assembly
23	10/12410	Magnet. Main Gas Valve
24	10/11935	Piezo Ignitor
25	10/13008	Regulator Assembly - NG
	10/12989	Regulator Assembly - LP Gas
26	10/14639	Button - Stop
27	10/13705	Button - Start
28	10/14641	Button - Ignitor
29	10/13486	Thermostat Bellows and Bulb
30	20/14834	'O' Ring - Thermostat Sensing Bulb
31	10/14536	Thermostat Assembly Complete
32	10/11904	Pin, Stat Assembly
33	10/14637	Cold Inlet Throttle
34	10/12284	Cold Water Inlet Screen
35	20/12335	'O' Ring - Sensing Tube
36	10/13495	Long Sensing Tube
37	10/14923	Short Sensing Tube
38	10/13561	Diaphragm Housing Assembly
39	10/12460	Diaphragm EPDM W/Plate
40	20/15360	'O' Ring - Ball Disk
41	10/12373	Pin, Automatic Valve Assembly
42	20/11822	'O' Ring - Diaphragm Drive Pin
43	10/12458	Automatic Valve Assembly - NG
	10/12803	Automatic Valve Assembly - LP Gas
44	10/12848	Manifold Gasket
45	10/12345	Stainless Burner
46	19/12780	Standard Orifice/Inj. - NG
	19/12782	Standard Orifice/Inj. - LP Gas

Appliances, Services And Parts
www.asapheat.com
 5812 Antigua Drive
 Port Orange, FL 32127